


IMC05B02-E1

In order to achieve maximum performance and ensure proper operation of your new instrument, carefully read all the instructions in this manual. Please place the manual in a convenient location for easy reference. This manual describes the parts description and basic key operations of the RB100/400/900.

For detailed handling procedures and key operations, contact Durex Industries:

Phone 847-639-5600  
FAX 847-639-2199  
E-mail [sales@durexindustries.com](mailto:sales@durexindustries.com)

## 1. PARTS DESCRIPTION



(1)	Measured value (PV) display [Green]	Displays Measured value (PV) or various parameter symbols.
(2)	Unit display [Green]	Displays the temperature units (°C or °F) of displayed data and the units (%) of the Manipulated output value (MV).
(3)	Set value (SV) display [Orange]	Displays Set value (SV), Manipulated output value (MV) or various parameter set values.
(4)	Set lock display [Orange]	Lights when the settings are locked.
(5)	AT lamp [Green]	Flashes when Autotuning is activated. (After Autotuning is completed: AT lamp will go out) Light during Startup tuning (ST) execution.
	Output lamp [Green]	OUT1: Lights when Output 1 is turned on. OUT2: Lights when Output 2 is turned on. Lamp indication becomes as follows for Current output and Voltage output. For an output of less than 0 %: Extinguished For an output of more than 0 %: Lit
	MAN mode lamp [Green]	Lights when operated in Manual (MAN) mode.
	STOP lamp [Green]	Lights when control is stopped (STOP). Blinks when control is stopped (STOP) by the Timer function.
	DO (digital output) lamp [Orange]	Lights when the Event (DO1 to DO4) output corresponding to each lamp is ON.
(6)	STEP set value lamp [Orange]	When the step SV function or the Timer function is used, the lamp corresponding to the currently used Set value (SV1 to SV4) lights.
(7)	Set (SET) key	Used for parameter calling up and set value registration.
(8)	Shift key	Shift digits when settings are changed. Used to switch monitor items, RUN/STOP, and modes.
(9)	Down key <sup>1</sup>	Decrease numerals.
(10)	Up key <sup>1</sup>	Increase numerals.
(11)	Loader communication connector (Standard equipment)	Setting and monitoring on a personal computer (PC) is possible if the controller is connected with our cable to a PC via our USB communication converter COM-K-1 (sold separately) <sup>2</sup> . Our communication software <sup>3</sup> must be installed on the PC.


<sup>1</sup> Also used to switch items within Mode switching (AUTO/MAN, Set data lock, and Interlock release).

<sup>2</sup> For the COM-K, refer to COM-K Instruction Manual (IMR01Z01-E□).

<sup>3</sup> Only available as a download from our website.


 To avoid damage to the instrument, never use a sharp object to press keys.

## 2. OPERATION FLOW




## 4. SETTING EXAMPLE


● Set Set value 1 (SV1) to 200 °C




● Set Event 1 set value (EV1) to 20 °C




- **Set Autotuning (AT)**




● Set 20 °C for Proportional band (P) of PID control




● Switch from Auto (AUTO) mode to Manual (MAN) mode



● Set Manipulated output value (MV) to 50 % in the Manual mode



### 3. OPERATION MENU



## Parameter Setting Mode


Change parameters related to control such as PID values.

F04 to F09 indicate group numbers used in Non-display of block and Set lock level in Engineering mode.

Parameters in F01 to F03 as well as F10 are not displayed with the factory default setting.

 Some parameters are not displayed depending on the model and the specifications

[Figures on the SV display shows a "factory set value."]



 For parameters in the Parameter setting mode, refer to **4. PARAMETER SETTING MODE** in **RB series Parameter list (IMC05B03-E□)**.



